

---

---

# **ProMove-V**

## **Wireless Inertial Sensing Platform**

**User Manual**

**v1.0.6**

---

---





# Contents

<b>1</b>	<b>Introduction</b>	<b>4</b>
<b>2</b>	<b>Safety Instructions</b>	<b>6</b>
<b>3</b>	<b>Setup</b>	<b>7</b>
3.1	System Description . . . . .	7
3.2	Node LEDs and Button . . . . .	8
3.3	Gateway Front and Back Panes . . . . .	9
3.4	Attachments . . . . .	11
3.5	Recharging the Batteries . . . . .	13
3.6	On-board Storage . . . . .	14
3.7	Reference System Axes . . . . .	15
3.8	Installing the Application . . . . .	16
3.8.1	Windows . . . . .	16
3.8.2	Linux . . . . .	16
3.8.3	macOS . . . . .	17
<b>4</b>	<b>Inertia Studio</b>	<b>18</b>
4.1	Main Screen . . . . .	18
4.1.1	Toolbar and Menu . . . . .	19
4.1.2	Plots . . . . .	21
4.1.3	Information Area . . . . .	22
4.2	Connecting to a Device . . . . .	24
4.2.1	Connecting to a Device Using the Toolbar . . . . .	24
4.2.2	Connecting to a Device Using the Menu . . . . .	24
4.3	Logging to File . . . . .	26
4.4	Logging to Flash . . . . .	28
4.4.1	Starting and Stopping a Flash Log . . . . .	28
4.4.2	Downloading a Flash Log . . . . .	29
4.4.3	Deleting Flash Logs . . . . .	30
4.5	Filling in Lost Samples . . . . .	31
4.5.1	Automatic . . . . .	31
4.5.2	Manual . . . . .	32
4.6	Exporting a Logfile . . . . .	33
4.6.1	CSV Settings . . . . .	34
4.6.2	MAT Settings . . . . .	35
4.6.3	Visual3D Settings . . . . .	36
4.6.4	ITLOG Settings . . . . .	37
4.7	Replaying a Logfile . . . . .	38
4.7.1	Real-Time . . . . .	38



4.7.2	Analysis . . . . .	39
4.8	Configuring the Sensors . . . . .	40
4.8.1	Global Settings . . . . .	41
4.8.2	Accelerometer Settings . . . . .	43
4.8.3	Compass Settings . . . . .	44
4.8.4	Gyroscope Settings . . . . .	45
4.8.5	Barometer Settings . . . . .	46
4.8.6	High-G Accelerometer Settings . . . . .	47
4.8.7	Temperature Settings . . . . .	48
4.8.8	GNSS Settings . . . . .	49
4.8.9	Status Settings . . . . .	50
4.8.10	Sampling Channels . . . . .	51
4.9	Calibrating the Sensors . . . . .	52
4.10	I/O Functionality . . . . .	53
4.10.1	Trigger Output . . . . .	53
4.10.2	Trigger Input . . . . .	54
4.10.3	Sync Output . . . . .	54
4.10.4	Sync Input . . . . .	55
4.11	The Tracker . . . . .	56
4.12	GNSS Map . . . . .	57
4.13	Appearance and Preferences . . . . .	59
4.13.1	Layout Configuration . . . . .	59
4.13.2	Preferences . . . . .	61
4.14	Updating the Firmware . . . . .	67
<b>5</b>	<b>The Orientation Algorithm</b>	<b>69</b>
<b>6</b>	<b>Performing an Experiment</b>	<b>70</b>
6.1	Experiment Preparation . . . . .	70
6.2	Reading and Aligning CSV Log Files . . . . .	71
<b>7</b>	<b>Troubleshooting</b>	<b>73</b>
7.1	Green LED blinks during charging . . . . .	73
7.2	Unresponsive Device . . . . .	73
7.3	Retrieving an Unreachable Device . . . . .	73
7.4	Slow Signals in Inertia Studio . . . . .	73
7.4.1	Lowering the Plot Update Speed . . . . .	73
7.4.2	Reducing the Number of Plots or Nodes . . . . .	74
7.4.3	Enabling Hardware Acceleration and Multi-threaded Rendering . . . . .	74
7.5	Manually Installing the Inertia Driver . . . . .	74



# 1 Introduction

**ProMove-V** is the new-generation **waterproof and dustproof wireless Inertial Measurement Unit (IMU)** of the ProMove series. Using Inertia's **high-speed and low-power wireless technology**, a network of tens of ProMove-V's can sample and stream all sensor data at high data rates within **100 ns synchronization accuracy** across all devices.

ProMove-V features a complete set of **ultra-low-noise** digital sensors, offering multi-modal and multi-DoF (degrees of freedom) sensor data:

- 3-D low-range acceleration
- 3-D high-g acceleration
- 3-D turn rate / gyroscope
- 3-D magnetic field intensity / compass
- Barometric pressure (optional)
- GNSS (optional) for localization and tracking

The sensor data is transmitted wirelessly to a central node, the **Inertia Gateway**, which connects to the computer through USB and acts as the master hub for data collection and sensor configuration over-the-air. The **Advanced** version of the Inertia Gateway provides additional features such as synchronized trigger and clock for external systems, as well as Raw Ethernet data transfer support.

The number of devices in the network scales with the sampling rates: for example, a network can have **39 nodes** operating (sampling and communicating) at **200 Hz**, 19 nodes operating at



**Figure 1: ProMove-V sensor node**



500 Hz or 9 nodes operating at 1000 Hz.

ProMove-V is also equipped with at least **16 GB** of internal storage. All sensor samples are logged internally, in addition to being sent over-the-air. Any information lost during the wireless transmission can be recovered at the end of each measurement round.

The **Inertia Studio** software (freely available on our website) is the interface for visualizing the incoming data in real-time and configuring all devices in the network and all sensors. Full access to the **raw sensor data** is provided to the user, as well as **3-D orientation information**, expressed as quaternions and Euler angles. C++, Java and Android SDKs, along with examples, are also available for integration with custom applications.

ProMove-V is carefully designed for good ergonomics. The curved design makes mounting and wearing on body parts comfortable, without affecting stability in case of surface mounting.

Please read the safety instructions in Section 2 carefully. Information about warranty and liability can be found at: <https://inertia-technology.com/terms-and-conditions/>.



## 2 Safety Instructions

To avoid a potential safety hazard, please follow the safety instructions below:

- Do not exceed the maximum input voltage of 5V.
- Only connect to CE-certified computers and USB-adapters.
- Operate the product at temperatures between 0 and 35°C.
- Do not charge the product if wet.
- Once fully charged, remove the product from the charger.
- Protect the product from violent handling, drops on hard surfaces, excessive shocks or mechanical stress.
- Do not open, crack, pinch or mutilate in any way the product.
- Do not use the product if it appears damaged or tampered with in any way.
- Do not attempt to replace the battery, open the enclosure or disassemble the product.
- Turn off the product before entering an area with potentially explosive atmosphere.
- Do not overheat the product by exposure to high temperatures or direct sunlight.
- Do not dispose the product in fire.
- Do not discard the product in the trash. Follow proper electronic and battery waste disposal protocol, as dictated by local authorities.
- Keep the product out of the reach of children.



## 3 Setup

This section describes the high-level system setup.

### 3.1 System Description

The default system consists of a number of ProMove-V sensor nodes, the Advanced Inertia Gateway and Inertia Studio (PC Software) for monitoring and logging the inertial data. The sensor nodes communicate wirelessly with the gateway in the 2.4 GHz ISM band. The gateway is connected through the mini-USB connector or the Ethernet connector with a PC that runs Inertia Studio.

C++ and Java SDKs are available for developing custom applications that interact with Inertia devices. The SDKs allow implementations on both desktop and mobile Android platforms.

Figure 2 shows the typical system setup with an USB connection between the Advanced Inertia Gateway and the PC running Inertia Studio.




Figure 2: System setup with an USB connection



Figure 3 shows the system setup with an Ethernet connection between the Advanced Inertia Gateway and the PC running a custom application using Inertia SDK.




Figure 3: System setup with an Ethernet connection

### 3.2 Node LEDs and Button

The LEDs and the multifunctional button are located on top of the ProMove-V sensor node, as shown in Figure 4.

The **green LED** indicates the node is charging: it stays lit while the battery is charging and it turns off when the battery is fully charged. If the green LED starts blinking during the process, this indicates a faulty state and the node will not charge. See Section 7 about Troubleshooting for more information.

The **blue LED** indicates the node is turned on and sampling data. The blinking rate is determined by the sampling rate. The number of blinks has the following meaning:

- **Single blink:** Not transmitting data.
- **Double blink:** Transmitting data via USB or wireless. Synchronized nodes should blink at the same time.



**Figure 4: The ProMove-V node top view with green and blue LEDs**

- **Five blinks:** Logging to flash memory.

The button has the following functionality:

- **Pressing short once:** Turns the node on.
- **Pressing short twice:** Starts or stops logging to the flash memory.
- **Pressing long once:** Turns the node off. Pressing more than 5 seconds forces the node to shut down.

### 3.3 Gateway Front and Back Panes

Figure 5 shows the front and back of the Advanced Inertia Gateway. On the front, the gateway has two BNC connectors and four **blue LEDs** with the following functionality:

- **RX:** The gateway is receiving data.
- **TX:** The gateway is transmitting data.
- **Power:** The gateway is powered on.
- **Sync:** The gateway is synchronized with an external signal.

The *EXT SYNC 1* and *EXT SYNC 2* connectors can be configured as *Input* or *Output*, with either *Trigger* or *Sync* functionality. See Section 4.10 for more information.

The backside contains a DC power connector, antenna, mini-USB connector and an *100BASE-TX* Ethernet connector. The gateway can be connected using the mini-USB or the Ethernet connector to the PC.

When using the Ethernet connector, the gateway can be connected directly to the network adapter of the PC using an Ethernet cable, or to a (wireless) switch/router in the same local network as the PC. Inertia Studio requires Npcap or WinPcap on Windows and libpcap on Linux



and macOS to access the network adapter and receive the Raw Ethernet data. The gateway has a local MAC address based on its serial number, e.g. 02:34:56:78:xx:xx, where xx:xx is the serial number. The gateway sends its data to broadcast address ff:ff:ff:ff:ff:ff using EtherType protocol 0xbabe.



**Figure 5: The front and back of the Advanced Inertia Gateway**




### 3.4 Attachments

Velcro straps of 40 cm in length are provided as part of the ProMove-V sensor kit. They can be attached through the handles of the ProMove-V sensor node for mounting on body parts or clothing, such as wrist, ankle or shoe, as shown in Figure 6.



**Figure 6: Examples of attaching the ProMove-V to the wrist and shoe**

Attaching a velcro strap to the handles of ProMove-V sensor node can be done as described in Figure 7.



**Figure 7: Attaching a velcro strap to ProMove-V**



### 3.5 Recharging the Batteries

The internal battery of the ProMove-V sensor node should be periodically recharged. This can be done by using a cable connecting the USB-C connector of the sensor node to a computer or a standard USB charger. It is recommended to power off the sensor node before charging.

Alternatively, a set of maximum ten ProMove-V sensor nodes can be charged by using the ProMove-V charging cradle, see Figure 8.




**Figure 8: ProMove-V charging cradle**


To charge a set of ProMove-V sensor nodes using the charging cradle, follow the instructions below (see also Figure 9):

1. Place each sensor node in a charging pad of the cradle, with the charging port pointing towards the USB-C connector.
2. Slide the sensor nodes into the USB-C connector until complete insertion.
3. Connect the charging cradle to the AC/DC power supply using the 4-PIN connector.
4. Connect the power supply to the mains.

To remove a sensor node from the charging cradle, the node must be first disconnected from the USB connector by pushing it away from the connector. After that, the sensor node can be removed from the cradle pad. See Figure 10 for more information about removing a sensor node.



**Figure 9: Inserting a ProMove-V sensor node into the charging cradle.**



**Figure 10: Removing a ProMove-V sensor node from the charging cradle.**

The incorrect removal of the sensor node while still plugged in the USB connector may cause damage to the cradle or sensor node (see Figure 11).



**Figure 11: Incorrect removal of a ProMove-V sensor node from the charging cradle.**

A fully drained battery takes approximately 55 minutes to recharge. During charging, the green LED of the ProMove-V node is on. Monitoring the battery voltage can be done using Inertia Studio (see paragraph 4.1.3.2).

### 3.6 On-board Storage

ProMove-V sensor nodes are equipped with (at least) 16 GB flash memory.

The flash memory is used to store the following data:

- **The sensor node device configuration**, including the global parameters, the wireless options and the configuration of the sensors (for information about changing, storing and clearing the configuration, see Section 4.8).



- **The sensor data**, the sampled data of all enabled sensors. More information about storing data in the flash memory of a sensor node device can be found in Section 4.4.

### 3.7 Reference System Axes

Figure 12 shows a ProMove-V node and the reference system axes (X, Y and Z) to which the on-board sensors are aligned.



**Figure 12: The ProMove-V node and the reference X, Y and Z-axis**



## 3.8 Installing the Application

This section explains the installation of the Inertia Studio application on various operating systems. For information on performing an measurement with *nexoDAQ*, please see Section 6.

The Ineria Studio application runs under Windows, Linux and macOS operating systems. In the following, we describe the installation procedure in each of these environments.

### 3.8.1 Windows

On a Microsoft Windows computer, unzip and run the Inertia Studio setup executable. During the setup process, the Inertia driver and the Visual C++ redistributable are installed (Figure 13). This may require a computer reboot. Choose a destination folder and press the **Install** button (Figure 13).




Figure 13: Inertia Studio installation in Windows

### 3.8.2 Linux

In Linux Ubuntu, install the package with the following command:

```
sudo dpkg -i inertiasstudio-[version].deb
```



### 3.8.3 macOS

On a macOS device, open the \*.dmg file as follows:

- On an *Apple silicon* device, open the *arm64* version of the \*.dmg file.
- On an *Intel* device, open the version without *arm64* in the \*.dmg file name.

Afterwards, drag the Inertia Studio application to the Applications, as shown in Figure 14.



**Figure 14: Inertia Studio installation in macOS**



## 4 Inertia Studio

Inertia Studio can be used for realtime visualization of sensor data, logging of sensor measurements and pre-computed orientation, and configuration of sensor and wireless parameters. This section describes Inertia Studio (v3.7.3) in more detail.

Inertia Studio is available for Microsoft Windows, Ubuntu Linux and macOS.

### 4.1 Main Screen

Figure 15 shows the main screen of Inertia Studio, which is divided in the following areas:

- The menu and toolbar at the top (described in Section 4.1.1)
- The sensor data plots in the middle (described in Section 4.1.2)
- The information area at the bottom (described in Section 4.1.3)

In the following, these three areas are presented in detail.



Figure 15: Inertia Studio with six nodes, showing data from the accelerometer, compass and gyroscope



### 4.1.1 Toolbar and Menu

The toolbar is used to quickly access the most used functionality of Inertia Studio. This section describes the default buttons of the toolbar, from left to right (see Figure 16).




Figure 16: Inertia Studio menu and toolbar

- **Connect / Disconnect**

The *Connect / Disconnect* button can be used to quickly connect to, or disconnect from an Inertia device. The drop-down menu associated with this button opens a list for selecting the target device. See Section 4.2 for more information.

- **Record / Stop**

When connected to a device, the *Record / Stop* button can be used to quickly start and stop logging/recording to file (see Section 4.3). If timed recording is enabled, a small clock overlay is shown on the icon. The drop-down menu associated with this button offers rapid access to the *Logging Configuration* window (see Section 4.3). The user can also quickly set the duration of the recording using time-presets.

- **Pause / Resume**

The *Pause / Resume* button is enabled when replaying a logfile. It can be used to pause and resume the replay.

- **Sensor Settings**

The *Sensor Settings* button opens the *Sensor Settings* window (see Section 4.8).

- **Preferences**

The *Preferences* button opens the *Preferences* window (see paragraph 4.13.2.2).

- **Hide / Show**

The *Hide / Show* button toggles between hiding and showing the data in the plots. The drop-down menu associated with this button opens a list for selecting the target nodes for which the data is hidden or shown. A small sign (i.e. red cross or yellow triangle) on the icon indicates that some data is hidden. This button does not influence the logging.

- **Clear (F5)**

The *Clear* button, or F5, clears the plots, legend and node lists. This button does not influence the logging.

- **Layout**

The *Layout* button opens the *Layout Wizard* (see Section 4.13.1) and has a drop-down menu to switch between layouts.



- **Tracker**

The *Tracker* button opens the *Tracker* window (see Section 4.11).

- **Zoom In (F3) / Zoom out (F4)**

The *Zoom* buttons, or F3 and F4, can be used to zoom the X-Axis of all plots in or out.

The menu allows access to all the options of Inertia Studio and has the following items:

- **File**

- Connect* opens the *Connection Configuration* window (Section 4.2).
- Record* opens the *Log to File* (Section 4.3) and *Log to Flash* (Section 4.4.1) windows.
- Replay* opens the *Replay* window (Section 4.7).
- Download* opens the *Download Logfiles* window (Section 4.4.2).
- Fill-in Lost Samples* opens the *Fill Loss* window (Section 4.5).
- Export* opens the *Export Logfiles* window (Section 4.6).
- Exit* closes Inertia Studio.

- **Configuration**

- Sensor Settings* opens the *Sensor Settings* window (Section 4.8).
- I/O Settings* opens the *I/O Settings* window (Section 4.10).
- Sensor Calibration* opens the *Calibration Configuration* window (Section 4.9)..
- Preferences* opens the *Preferences* window (paragraph 4.13.2.1).
- File Types* opens a sub-menu to configure the supported file types.
- Power Down* allows the user to remotely power down specific sensor nodes.

- **View**

- Layout Wizard* opens the *Layout Wizard* (Section 4.13.1).
- Tracker* opens the *Tracker* window (Section 4.11).
- GNSS Map* opens the *GNSS Map* window (Section 4.12).
- Detailed Status* opens the *Detailed Status* window (paragraph 4.1.3.4).
- Toolbox* can be used to show or hide the *Zoom and Pan* sliders and the *Log and Legend* in the information area.
- Toolbar* can be used to change the appearance of the toolbar. The toolbar can be hidden using the *Hide* option. The size of the toolbar icons can be modified to *Small*, *Medium* and *Large*. *Show Text* allows to show or hide the text below the icons. *Show I/O Buttons* adds two extra buttons to the toolbar for I/O functionality.
- Show Data* toggles between showing and hiding the incoming data in the plots.
- Clear Plots (F5)* clears the plots, legend and node lists.
- Full Screen (F11)* shows Inertia Studio in full-screen mode.

- **Help**

- Check for Updates* checks if a new version of Inertia Studio is available, or if new firmware for the connected nodes is available.
- Firmware Update* opens the *Firmware Update* window (Section 4.14).




- Software Web Site* opens the Inertia Technology software website.
- Manual (F1)* opens the Inertia Studio manual.
- About* shows the current Inertia Studio version and build date.

#### 4.1.2 Plots

Inertia Studio can be configured to display a customizable number of plots that show in real-time the sensor data, status data (e.g. battery voltage, lost samples) and processed data (e.g. orientation, Norm, FFT). The shown plots and layout can be customized via the Layout Wizard (see Section 4.13.1). The X-axis of the time-plots represents the number of seconds since the gateway was started.

The mouse can be used to zoom and pan the plot. Holding the left mouse button while moving the mouse creates a zoom-box. Releasing the left mouse button zooms to the selected data. Note that *Auto-scaling* resets the Y-axis zoom. A plot can be panned by holding the right mouse button and moving the mouse. By default, the X-axis is automatically set to the latest received data. Disable *Show Data* or use the pan slider (see Section 4.1.3) to prevent this.

Right-clicking on a plot provides the following options (see Figure 17):



**Figure 17: Plot right-click pop-up menu**

- **Fit:** Fits all received data in the plot.
- **Zoom in/out:** Zooms the plot in or out. The *Zoom* buttons in the toolbar and the *Auto-scaling* option (see paragraph 4.13.2.2) can be used to reset the zoom.
- **Lock X-axis...:** Locks the X-axis to a specified range by showing a pop-up window in which the minimum and/or maximum values of the X-axis can be set. When the axis is locked, a ← and/or → symbol is shown at the bottom right and/or left corner of the plot. This option is only enabled for FFT plots.
- **Lock Y-axis...:** Locks the Y-axis to a specified range by showing a pop-up window in which the minimum and/or maximum values of the Y-axis can be set. When the axis is locked, a ↑ and/or ↓ symbol is shown at the left top and/or bottom corner of the plot. Locked plots do not auto-scale.
- **Auto-Scale Y-axis:** Toggle automatically scaling the Y-axis. This overrules the global auto-scaling option in paragraph 4.13.2.2.



- **Save as SVG...:** Save the plot as a SVG image.

### 4.1.3 Information Area

The information area at the bottom of the main screen shows the list of event messages and the legend with connected nodes. In addition, a zoom-slider, a pan-slider and buttons to set and get the time of the nodes can be added to the information area via the menu (*View, Toolbox*).

#### 4.1.3.1 Notification Area

Event notifications are displayed in the notification area. They give information about the outcome of certain actions, such as plugged-in or removed devices, connecting to or disconnecting from a device, starting or stopping logging, downloading or exporting files, modifying sensor configurations, etc. By clicking the header of the time column, the notifications can be sorted in ascending or descending time order. Right clicking an item in the list provides the following options: copy the selected line(s), copy all lines, and clear the notification area.

The icon in front of a message indicates the notification type. A green check-mark means success, a red cross means error, an orange triangle means warning and a blue circle means information.

#### 4.1.3.2 Legend

The legend contains a list of all the nodes of which sample data is received. The first column shows the line colour and ID for each node. The *NodeID* can be extended with a name in paragraph 4.13.2.3. The second column (*Signal*) displays the radio signal strength (when connected via a gateway), or the transmission type (when connected via USB). The third column (*Battery*) shows the battery level for each node, and whether the node is charging. The fourth column (*Loss*) shows the percentage of lost samples over the last period (see also paragraph 4.13.2.1). The fifth column (*Flash*) shows whether the node is logging to flash or not. The sixth column (*GNSS*) shows whether a node equipped with a GPS or GNSS sensor has a fix or not. The legend can be sorted on every column. Columns can be hidden by right-clicking the column header. Double-clicking on the legend opens the *Detailed Status* window (see paragraph 4.1.3.4).


The radio strength is updated every second. The battery level is, by default, updated every ten seconds. The loss update interval can be configured via the global preferences (see paragraph 4.13.2.1).

#### 4.1.3.3 Zoom and Pan

The *zoom* and *pan* sliders can be used to change the visible data in the plots. The *zoom* slider behaves the same as the zoom buttons in the toolbar (Section 4.1.1) and allows to zoom the X-axis in or out. The *pan* slider allows the move back in time and show older data. The maximum number of seconds to pan can be configured in the global settings (*Plot History* in paragraph 4.13.2.1). If panning is active, plots are not updated with new sample data.

#### 4.1.3.4 Detailed Status

The *Detailed Status Overview* window (see Figure 18) can be accessed by double clicking an item in the legend or via the *View* menu, sub-menu *Detailed Status*. The window shows detailed information about the battery level, CPU temperature, external input, RSSI and sample loss of the connected nodes. The plots are cleared when (re)connecting to a device or when using the *Clear* button.



**Figure 18: Detailed Status information**

The battery, temperature and external input plots are updated when status information from a node is received via automatic status messages (usually every ten seconds). The RSSI plot is updated every second with the average value of the received RSSI information. The sample loss plot is updated every second with the detected sample loss. The time on the X-axis is the system time.

A checkbox is available to disable automatic updating of the plots. This can be used to prevent the plots from resetting when zoomed in. The *Send Request* button broadcasts a message to all nodes with a request to send the current battery and CPU temperature value. The *Plots* button can be used to show or hide specific plots.



## 4.2 Connecting to a Device

In this section we describe how an Inertia device can be connected to the PC, using the following connections:

- **USB:** Any Inertia device can be connected to the PC using USB. The USB-C connector of the ProMove-V and the mini-USB connector of the gateway can be used for direct connection to the PC using a USB cable.
- **Ethernet:** The Advanced Inertia Gateway can also be connected using Ethernet to the PC. The gateway can be connected either directly to the network adapter of the PC using an Ethernet cable, or indirectly using an Ethernet cable to a (wireless) switch or router that is in the same local network as the PC. Inertia Studio requires Npcap or WinPcap on Windows and libpcap on Linux and macOS to access the network adapter and receive the Raw Ethernet data.

The connection can be started via the *Connect* button in the toolbar or from the *File* menu item, option *Connect*.

### 4.2.1 Connecting to a Device Using the Toolbar


Pressing the arrow next to the *Connect* button in the toolbar opens the drop-down menu shown in Figure 19:

- The option *Connect...* opens the *Connection Configuration* window, which is explained in Section 4.2.2.
- The option *Available...* opens a pop-up window with all the available devices, including the active network adapters. A setting in the *Global Preferences* (Section 4.8.1) can hide the network adapters from the list of available devices.
- Below the line, a list is shown with the names of the available Inertia devices connected through USB and the active network adapters, i.e. the local and/or the wireless network adapters. Next to them, the corresponding port numbers are given. A • symbol in front of the name indicates the device is selected. A ► symbol in front of the name indicates the device is connected.

Select the desired device and press the *Connect* button in the toolbar to connect.

### 4.2.2 Connecting to a Device Using the Menu


The option *Connect* from the *File* menu item opens the *Connection Configuration* window from Figure 20. The window shows a list with *Stored Configurations*, i.e. all the connections to Inertia devices that were previously used and those that are currently available. The list includes the devices connected through USB and the active network connections, e.g. the local and/or the wireless network connections. The port name (“com\*” on Windows and “/dev/\*” on Linux)



**Figure 19: Connect drop-down menu**

is shown next to the device name. A green dot indicates the device is available. The ► symbol indicates the device is connected.

By pressing the *Available?* button, the list is updated and a pop-up window with all the available devices is shown. The *Show* button loads the selected connection into the main screen. The *Add...* button can be used to manually add a device to the list if it is not automatically detected. The *Remove* button removes a selected device from the list. The *Connect/Disconnect* button starts and shows, or stops, the selected connection with the device.



**Figure 20: Connection Configuration**




### 4.3 Logging to File

When connected to an Inertia device, the incoming data can be stored/recorded in a log file. The default file format is *itlog* (Inertia Log File). Incoming samples, node information and configurations, etc, are stored in the file. An *itlog* file can be exported to a different format (see Section 4.6). The *itlog* format also supports filling in lost samples after an experiment is finished, see Section 4.5.

There are two options that can be used to enable logging to file:

1. By using the *Record* button from the toolbar; to change the settings for creating a log file, select the *Log to File...* option from the drop-down menu of the *Record* button; this option opens the *Logging Configuration* window for logging to file (see Figure 21).
2. By selecting the *Log to File...* option from the *File* menu, *Record* item; this option opens the same *Logging Configuration* window for logging to file (see Figure 21).



**Figure 21: Log to File Configuration**

In the *Logging Configuration* window, the settings for creating a log file can be modified as follows:

- **Filename:** The name of the log file. The default file format is *itlog*.
- **Description:** A description that can be added to the beginning of the (exported) log file.



- **Compression:** An optional compression format used for the log file, resulting in a smaller file size. Supported compression methods are: **gzip** (.gz, GNU Zipped Archive), **bzip** (.bz2, BZIP2 Compressed Archive) and **zlib** (.Z, UNIX Compressed Archive).
- **Unique Filename:** Selects the way of handling existing log files with the same name:
  - **Overwrite:** The existing file is overwritten.
  - **Auto-Number:** Files are numbered in sequence with the following naming convention: *<filename>[\_No].ext*, where *ext* is the file extension and *No* is the sequence number; this number is automatically increased every time a log file with the same name is created.
  - **Date in Filename:** The current local or UTC date and time are added to the filename; the timestamp is formatted as described in ISO 8601 (i.e. *[YYYYMMDDThhmmss\_]<filename>.ext*).
- **Stop Logging After:** This option can be enabled to automatically stop logging to file. The duration can be entered as *hh:mm:ss*. When active, a countdown is shown in the toolbar.
- **Start Flash Logging:** Starts (and stops) logging to flash when a log file is created. This option is enabled by default when *Fill-in Lost Samples* is enabled.
- **New File Every:** Start logging to a new file once the provided number of seconds or file size is reached. *Fill-in Lost Samples* and *Export* should be disabled.
- **Fill-in Lost Samples:** Fills-in lost samples when logging to file is finished (see Section 4.5).
- **Export:** Exports the log file when logging to file (including filling in lost samples) is finished. The button opens the Section 4.6 window.

If a device is connected, the *Record* button can be used to save the settings and start creating a log file. If the device is disconnected, the *Save* button can be used to save the current settings. The *Stop* button can be used to stop logging. These buttons behave similarly to the *Record / Stop* button in the toolbar, described in Section 4.1.1.




## 4.4 Logging to Flash

ProMove-V nodes have an internal flash memory that can be used to store sensor data. Flash logs are used to fill in lost samples after an experiment, as described in Section 4.5. Flash logs can also be created manually, as described in Section 4.4.1. Section 4.4.2 describes the way the flash logs can be downloaded to the PC.

### 4.4.1 Starting and Stopping a Flash Log

The *Log to Flash* option from the *File* menu, *Record* item, opens the *Logging Configuration* window for logging to flash (see Figure 22).

The *Logging Configuration* window shows the list of all devices in the network. For each node in the list, the ► symbol indicates whether the node is logging to flash or not. If a timer is used when starting the flash log (the *Stop Logging After* option is enabled), a countdown is visible in the list. The last column in the list shows the sensor data types that are logged to flash (see Section 4.8 to enable or disable sensors).



**Figure 22: Log to Flash Configuration**

The *Start* / *Stop* buttons can be used to send a command to the checked node(s) to start or stop logging to flash. The *Stop Logging After* option activates a timer for stopping the flash logging. Closing Inertia Studio while a timer is active does not determine a node to stop logging to flash.



The format of the timer is *hh:mm:ss*. During logging to flash, the blue led blinks in short bursts. Starting or stopping a flash log can also be done by pressing shortly twice on the button of the node (see Section 3.2).

When starting or stopping a flash log, a notification message appears in the information area at the bottom of the main screen with the response from the node, indicating success or failure. A failure can occur when logging to flash is already started (or stopped).

Flash logs are named *LOG<No>.LOG*, where *No* is the first available number starting from 1. The creation date of the flash log is also recorded. The date is based on the internal clock of the node. If the battery of a node is fully drained, the clock is reset, which can result in an incorrect creation date. The internal clock is automatically synchronized with the PC time when data from a node is received by Inertia Studio.

A ProMove-V sampling at 200 Hz with all sensors enabled uses about 24 MB of flash per hour.

#### 4.4.2 Downloading a Flash Log

Downloading a flash log can be done either wirelessly or through a USB cable, which is much faster. By selecting the *Download* option from the *File* menu, the *Download Flash Logs* window appears, as shown in Figure 23. When a node is selected in the drop-down list, status information about the internal flash is shown, and the *File list* is updated with the flash logs present on the internal flash of the node. The filename, file-size and creation date (local time) of each file is shown in the list. By selecting a node or using the *Refresh* button on the right hand side, the status information and file-list are updated. Active files (e.g. files currently being created) are not included in the file list.


To download a file, select it in the *File list* and adjust the following options:

- **Destination:** The name of the file (*itlog* format). Several wildcards are supported in the filename:
  - **{name} or %s:** Insert the full flash file name (without extension).
  - **{no} or %d:** Insert the number of the flash file (e.g. 34 for LOG34.LOG).
  - **{date} or %c:** Insert the creation date of the flash file (in ISO 8601 format).
  - **{id} or %i:** Insert the node ID.
- **Unique Filename:** Selects the way of handling existing log files with the same name (same as in Section 4.3).
- **Use Date from Flash File:** Set the creation date of the file to the date of the flash file.
- **Export:** Export the file when downloading is finished. Use the button to open the Export Settings. (see Section 4.6).



Press *Download* to start the download. If the node is transmitting data, transmission will be temporarily disabled until the download is finished.

During downloading, the progress is shown in the list. Information about the progress is also shown in the information area at the bottom of the main screen (see paragraph 4.1.3.1). When downloading is in progress, the *Cancel* button can be used to cancel the process. If a file is being downloaded, other files of the node can be queued so they will start downloading as soon as the current file is finished. Select one or more **LOG\*.LOG** files, adjust the file options, and press *Queue*.



**Figure 23: Download Flash Logs**

#### 4.4.3 Deleting Flash Logs

Flash logs can be removed from the flash memory using the *Format* button in the *Download Logfiles* window (Figure 23). This action removes all files from the internal flash memory. Formatting takes about 5 to 10 seconds. A message is shown when formatting is finished.

**Do not turn the nodes off during formatting!**



## 4.5 Filling in Lost Samples

When performing an experiment with wireless sensor nodes, there is almost always some data loss. This loss can be filled in automatically after the experiment is finished. This feature is available only for experiments performed with a gateway, when the sensor nodes are in *Synchronous* mode (see Section 4.8.1 for details about sampling mode). If the sensor nodes are in *Stand alone* mode, or if the sensor nodes are connected using a USB cable this feature is not available.

The sections below explain this process of filling in the lost samples.

### 4.5.1 Automatic

Enable *Fill-in Lost Samples* when creating a logfile (see Section 4.3). Once logging is stopped, a pop-up is shown informing that missing data will be filled in. Once continued, the *Fill-in Lost Samples* window is shown (Figure 24) and missing data is automatically filled in.

The process consists of three stages:

1. First, the existing logfile is analyzed and missing data of each node is identified. During this stage, a progress bar for each node is filled with blue bars. The tint of the color represents the amount of lost data: white is 100% loss, dark blue is 0% loss. The percentage inside the progress bar is the total percentage of samples available.
2. During the second stage, the missing data is requested wirelessly from the nodes (Figure 24). The progress bars are actively being updated to reflect the received data. The lighter segments change to dark-blue.
3. In the third stage, the received data is merged into the *itlog* file (Figure 25). The progress bars are filled with green bars to show the progress. If there is still some missing data, sections in a progress bar are made red and messages with information about the missing sections are added to the notification area. A manual restart could fill in the remaining missing samples (see Section 4.5.2).




Figure 24: Requesting




Figure 25: Merging

Once the process is finished, and if *Export* was enabled when the logfile was created, the file




is exported in the background. If the fill-loss process is canceled using the *Cancel* button, a pop-up asking to continue with export is shown.

#### 4.5.2 Manual

Filling in lost samples can also be started manually. Open the window via the menu (*File, Fill-in Lost Samples*) and expand the manual settings using the *Manual Settings* arrow (Figure 26). Provide the following parameters:

- **File(s):** One or more *itlog* files to be filled in.
- **Port:** The port used to access the node(s), usually the port of the gateway.
- **Export:** Export the *itlog* file when filling in lost samples is finished or canceled. Use the button to open the Export Settings. (see Section 4.6).
- **Backup:** Keep a backup of the unfilled file (named *<filename>\_BACKUP\_.itlog*).
- **Slots:** Temporarily change the number of slots (to a lower value) to increase the fill-loss speed. This should be equal or higher than the number of devices in the network. Leave empty or use *0* for the default number of slots.
- **Flash Diff (S):** The maximum time difference in seconds between the creation date of the pc file and the node's flash file.

Press *Start* to start the process.



**Figure 26: Manual settings**

The *Details* arrow expands the window and shows a list with all status messages. The messages can be copied or cleared using the *Copy* and *Clear* buttons. The *Auto-scroll* checkbox enables or disables automatic scrolling to the latest message.



## 4.6 Exporting a Logfile

Inertia Log Files of type *itlog* can be exported to different file types using the *Export Logfiles* window (see Figure 27), which can be accessed from the menu (*File, Export*). The following parameters can be modified:

- **Format:** The file format to export the *itlog* file to (Figure 28). Settings specific to the file format can be modified via the *Configure* button (see the next sections for available options).
- **Compression:** An optional compression format used for the exported file, resulting in a smaller file size. Supported compression methods are: **gzip** (.gz, GNU Zipped Archive), **bzip** (.bz2, BZIP2 Compressed Archive) and **zlib** (.Z, UNIX Compressed Archive).
- **Unique Filename:** Selects the way of handling existing log files with the same name (same as in Section 4.3).
- **Source(s):** The *itlog* file(s) to export or merge. The *Destination* filename is automatically updated to match the source name and the selected file format.

Use the *Start* button to save the settings and export the file(s). Active and previously exported files are shown in the *Activity List*. Double-clicking an item opens the exported file in its default program. An active item can be canceled using the *Cancel* button. Previously exported files in the activity list can be cleared using the *Clear* button. The folder of a selected item can be opened using the *Open Folder* button.




Figure 27: Export logfiles




Figure 28: File format options



### 4.6.1 CSV Settings

Inertia Log Files can be exported to a Comma Separated Values file (CSV). The CSV Settings can be modified in the *CSV Settings* window (see Figure 29), accessible via the menu (*Configuration, File Types, CSV Settings*) or from the *Export* window.

A CSV file starts with a header identifying each column. Each subsequent line in the CSV file consists of a timestamp and the sensor data sampled at that timestamp.

The following settings can be modified for the CSV file format:

- **One File per Node:** A separate file is created for each node; the node number is appended to the filename: `<filename>[_nodeNo].ext`. When disabled, one file with data from all nodes is created.
- **Repeat Previous Value:** When sensors have a lower sampling rate than the global sampling rate, empty values are added to the CSV file (no value between commas). . By using this option, instead of logging an empty value, the last received value is repeated until a new value is received.
- **Add Info to Beginning of File:** Add information such as node information, sensor settings, units of measurement, a description, etc, to the beginning of the log file. The information lines start with a #.

The sensor data added to the CSV file can be configured by (un)checking the desired *Columns*. The *Apply* button saves the settings and closes the window. The *Close* button discards any modified settings and closes the window.




Figure 29: CSV Settings



#### 4.6.2 MAT Settings

Inertia Log Files can be exported to a MatLab MAT file. The MAT Settings can be modified in the *MAT Settings* window (see Figure 30), accessible via the menu (*Configuration, File Types, MAT Settings*) or from the *Export* window.

The MAT file contains a global structure array with a field for each node structure. Each node structure contains four fields. Field *columns* contains the column names and indices of the columns, *fields* combines multiple columns into one field (e.g. *ax*, *ay* and *ax* into accelerometer), *data* contains the sensor data, and *samplingRate* contains the sampling rate.

The following settings can be modified for the MAT file format:

- **Struct Name:** The name of the global structure array.
- **MAT Version:** The MAT-file version (see MatLab documentation).
- **No. of Samples:** The number of samples in the MAT file. This option is not relevant when exporting an *itlog* file to MAT. Only when logging directly to a MAT file, the number of samples to store needs to be known beforehand. If more (or less) samples are logged, these are ignored (or filled with NaN).

The sensor data added to the MAT file can be configured by (un)checking the desired *Columns*. The *Apply* button saves the settings and closes the window. The *Close* button discards any modified settings and closes the window.




Figure 30: MAT Settings



### 4.6.3 Visual3D Settings

Inertia Log Files can be exported to a Visual3D ASCII file. The Visual3D Settings can be modified in the *Visual3D Settings* window (see Figure 31), accessible via the menu (*Configuration, File Types, Visual3D Settings*) or from the *Export* window.


The Visual3D ASCII file starts with a header identifying each column. Each subsequent line in the file represents a frame at a specific time point with data from all sensor nodes.

The following settings can be modified for the Visual3D file format:

- **Repeat Previous Value:** When a sensor value is missing, use the previous value when available or use the *Empty Value*.
- **Empty Value:** Use this value when there is no known sensor value.
- **Owner:** The source of the data.
- **Point Rate:** Add a point rate time signal and set the start time.
- **Analog Rate:** Add an analog rate time signal and set the start time.

When data of individual sensor nodes is in separate files, for example when downloaded from flash, it can be merged together before exporting to a Visual3D ascii file. Enable *Merge Before Converting* and provide an optional name to use for the merged file. Select all the files to merge in the *Export* window.

The sensor data added to the Visual3D file can be configured by (un)checking the desired *Columns*. The *Apply* button saves the settings and closes the window. The *Close* button discards any modified settings and closes the window.



**Figure 31: Visual3D Settings**



#### 4.6.4 ITLOG Settings

Inertia Log Files can be merged or rewritten. The ITLOG Settings can be modified in the *ITLOG Settings* window (see Figure 32), accessible via the menu (*Configuration, File Types, ITLOG Settings*) or from the *Export* window.


When multiple *itlog* files are selected in the export window, these will be merged together into one file. When one *itlog* file is selected, it will be parsed and rewritten.

By default, the source info of the new itlog file will be the same as the (first) source file. The source info can be changed by enabling the **Enable Replacing Source Info** checkbox. Use the **Load Info From Source File** button to fill the fields with the source info of the (first) source file.

The following fields can be modified:

- **Created Date:** Unix timestamp when the file was created (required).
- **Version Info:** Information about the application that created the file.
- **Original Filename:** The original name of the file, for example when the file was downloaded from the flash memory of a sensor node.
- **Description:** Extra information that was provided when creating the file (see Section 4.3).

The *Apply* button saves the settings and closes the window. The *Close* button discards any modified settings and closes the window.



**Figure 32: ITLOG Settings**



## 4.7 Replaying a Logfile

The *Replay Logfile* window can be used to replay a previously created logfile in real-time, or analyze and plot an entire logfile.




Figure 33: Replay Logfile window




Figure 34: Analyze Logfile window

### 4.7.1 Real-Time

Real-time replay has the following options:

- **Logfile:** The logfile to be replayed.
- **Hardware Type:** (CSV only) The hardware type of the device used in the logfile. This is necessary to determine to correct initial orientation in the tracker.
- **Rewrite Replay:** (CSV only) The logfile will be rewritten to a new file (same name, with *-replay* appended), and the orientation (Euler angles and/or quaternions) will be recalculated.
- **Sampling Rate:** The sampling rate used in the logfile. Used to calculate the *Read Interval*.
- **Number of Nodes:** The number of nodes in the logfile. This is used to calculate the *Read Interval*.
- **Read Interval:** The number of samples to read per second. The initial value is determined by the *Sampling Rate* and *Number of Nodes*, but the interval can be manually adjusted. During a replay, the slider can be used to change the speed of the replay.

A replay is started with the *Start* button, and stopped with the *Stop* button. During the replay, it can be paused with the *Pause* button. The buttons in the toolbar can also be used to control



the replay. Replays are added to the drop-down menu of the *Connect* button. Finished replays are removed from the drop-down menu when the *Available...* option is used.

#### 4.7.2 Analysis

Replay analysis can be used to analyze a logfile and detect timestamp issues. It detects *Rollbacks* (timestamp is lower than the previous timestamp), for example when the sampling rate is changed during the experiment. *Duplicate Timestamps* are detected when subsequent timestamp are the same. *Gaps* are detected when samples are lost.

It has the following options:


- **Logfile:** The logfile to be analyzed.
- **Rollbacks:** Detect and show timestamp rollbacks in the log.
- **Duplicate Timestamps:** Detect and show duplicate timestamps in the log.
- **Gaps:** Detect and show timestamp gaps in the log.
- **Show Sample Data in Plots:** Collect all the sample data and show them in the plots once analysis is finished. For large logfiles, this requires a lot of memory.

Analysis is started with the *Start* button, and stopped with the *Stop* button. During the analysis, it can be paused with the *Pause* button. Once the analysis is finished the data of the logfile is shown in the plots. When the plot layout is changed, *Reload Plot* can be used to recreate the plots. *Clear Results* will clear the log and remove the collected sample data from memory.



## 4.8 Configuring the Sensors

The *Sensor Settings* window can be used to modify the configuration of Inertia nodes. This window is accessible via the toolbar and via the *Configuration* menu, item *Sensor Settings*. Once a device is connected, the configuration options of the detected Inertia nodes is shown in this window.



**Figure 35: Sensor Settings**

Figure 35 shows the *Sensor Settings* window, which is divided in the following areas:

- *The node list area*, marked with **green** in Figure 35, contains the list of devices available via the currently selected connection. When a node is *selected*, its configuration options are shown in the sensor tree. When a node is *checked* by using the checkbox beside it, the actions of the buttons refer to this node. In Figure 35, all nodes are checked, so the configuration is applied to all these nodes after pressing the *Apply Settings* button.
- *The sensor tree*, marked with **red** in Figure 35, shows the available configuration options of the selected nodes in the node list. When choosing an option in the tree, the corresponding configuration settings are shown in the settings panel. The different configuration options in the sensor tree are discussed in the subsequent sections.
- *The buttons*, marked with **blue** in Figure 35, have the following functions:



- **Refresh** This button can be used to request *all* the configurations from *all* nodes. The purpose is to make sure that configurations are successfully applied and correctly retrieved by Inertia Studio.
- **Store** This button stores the current configuration of the *checked* nodes in their flash memory, so the settings are retained when the nodes are turned off. The button is *not visible* if configurations are automatically stored (paragraph 4.13.2.1).
- **Restore** This button can be used to restore *all* the configurations of the *checked* nodes. The nodes are reset to their factory-default settings.
- **Apply Settings** This button applies all the modified settings (shown bold in the sensor tree) to the *checked* nodes in the list. If no settings are modified, the currently shown settings are applied. If settings are stored automatically, a 15 second countdown is shown.
- **Close** This button closes the window, discarding all modified settings.
- *The settings panel*, marked with **yellow** in Figure 35, shows the settings available for the selected configuration option of the selected node in the node list. These settings are discussed in detail in the subsequent sections. When invalid or not recommended settings are used, these settings are marked with a red (invalid) or orange (not recommended) colour. Invalid settings cannot be applied. Error, warning and information messages are shown below the *Apply Settings* and *Close* buttons. The settings panel also contains a **Refresh** and **Restore** button at the top-left corner. These buttons can be used to refresh or restore the *selected* configuration of the *selected* node.


#### 4.8.1 Global Settings

By selecting the *Global* configuration option from the sensor tree, the global settings can be edited, as shown in Figure 36:

- **Transmit Data:** Data transmission can be switched off by unchecking the check-box. Nodes keep sampling (i.e. to store data in the flash memory).
- **Sampling Rate (Hz):** Selects the sampling rate used by the sensors. Some sensors may be limited to a lower sampling rate. When using *Synchronous* sampling mode, the default maximum number of nodes supported by the network for a selected sampling rate is shown on the right. The maximum sampling rate is 1000 Hz.
- **No. of Nodes:** The number of nodes in the network to which the device is currently configured. For gateways this can be modified to match the configuration of the node(s). For nodes this is automatically changed to match the gateway settings. The combination of *Sampling Rate* and *No. of Nodes* determine the number of samples in a radio packet. For best performance, this should be a round number.



- **Sampling Mode:** Inertia nodes can be configured to *Synchronous* or *Stand-alone* sampling. When sampling synchronously, the gateway dictates the time when the nodes take a sample. Nodes do not take samples until a gateway is detected. In stand-alone mode, each node decides on its own when to take a sample.
- **Transmit Type:** Data can be transmitted using *Wireless* (Radio), *USB* or both.
- **Frequency Channel:** Selects the frequency channel used by the Radio. To establish a connection, the channel of the nodes has to be the same as the channel of the gateway. When changing channel, it is recommended to first change the frequency channel of the nodes, and then the channel of the gateway.
- **Disable Radio:** Disable to radio, for example to save power. The device will not be accessible anymore, except via USB.




**Figure 36: Global Settings**



## 4.8.2 Accelerometer Settings

By selecting the *Accelerometer* configuration option from the sensor tree, the accelerometer settings can be edited, as shown in Figure 37:

- **Enabled:** Enables sampling of the accelerometer.
- **Transmit Data:** If the accelerometer is enabled, data will be transmitted. This is overruled by global transmission settings (see Section 4.8.1).
- **Log to Flash:** If the accelerometer is enabled, data will be logged to flash. See Section 4.4.1 about how to start a flash log.
- **Sampling Rate (Hz):** The sampling rate of the accelerometer (maximum 1000).
- **Range (g):** Sets the maximum acceleration that can be measured. Select from the supported options in the drop-down list. A lower range has a higher sensitivity.
- **Calibration:** Advanced option that adjusts the scaling and offset of each axis (see Section 4.9 for details about the calibration method).




**Figure 37: Accelerometer Settings**



### 4.8.3 Compass Settings

By selecting the *Compass* configuration option from the sensor tree, the compass settings can be edited, as shown in Figure 38:

- **Enabled:** Enables sampling of the compass.
- **Transmit Data:** If the compass is enabled, data will be transmitted. This is overruled by global transmission settings (see Section 4.8.1).
- **Log to Flash:** If the compass is enabled, data will be logged to flash. See Section 4.4.1 about how to start a flash log.
- **Sampling Rate (Hz):** The sampling rate of the compass (maximum 100 Hz).
- **Range (gauss):** Selects the magnetic full scale. Supported options are:  $\pm 4$ ,  $\pm 8$ ,  $\pm 12$  and  $\pm 16$  gauss. A lower scale has a higher sensitivity.
- **Calibration:** Advanced option that adjusts the scaling and offset of each axis (see Section 4.9 for details about the calibration method).




**Figure 38: Compass Settings**



#### 4.8.4 Gyroscope Settings

By selecting the *Gyroscope* configuration option from the sensor tree, the gyroscope settings can be edited, as shown in Figure 39:

- **Enabled:** Enables sampling of the gyroscope.
- **Transmit Data:** If the gyroscope is enabled, data will be transmitted. This is overruled by global transmission settings (see Section 4.8.1).
- **Log to Flash:** If the gyroscope is enabled, data will be logged to flash. See Section 4.4.1 about how to start a flash log.
- **Sampling Rate (Hz):** The sampling rate of the gyroscope (maximum 1000 Hz).
- **Range (°/s):** Sets the maximum rotational velocity the gyroscope can measure. Select from the supported options in the drop-down list. A lower range has a higher sensitivity.
- **Offset Correction:** The gyroscope has a factory, temperature dependent, offset. Enable an algorithm that zeros the gyroscope axes when no movement is detected.
- **Calibration:** Advanced option that adjusts the scaling and offset of each axis.




**Figure 39: Gyroscope Settings**



### 4.8.5 Barometer Settings

By selecting the *Barometer* configuration option from the sensor tree, the barometer settings can be edited, as shown in Figure 40:

- **Enabled:** Enables sampling of the barometer.
- **Transmit Data:** If the barometer is enabled, data will be transmitted. This is overruled by global transmission settings (see Section 4.8.1).
- **Log to Flash:** If the barometer is enabled, data will be logged to flash. See Section 4.4.1 about how to start a flash log.
- **Sampling Rate (Hz):** The sampling rate of the barometer (maximum 100 Hz).
- **Range (hPa):** Sets the pressure range the barometer can measure, which is 260-1260 hPa.
- **Calibration:** Advanced option that adjusts the scaling and offset.




**Figure 40: Barometer Settings**



#### 4.8.6 High-G Accelerometer Settings

By selecting the *Accelerometer (High G)* configuration option from the sensor tree, the high-g accelerometer settings can be edited, as shown in Figure 41:

- **Enabled:** Enables sampling of the high-g accelerometer.
- **Transmit Data:** If the high-g accelerometer is enabled, data will be transmitted. This is overruled by global transmission settings (see Section 4.8.1).
- **Log to Flash:** If the high-g accelerometer is enabled, data will be logged to flash. See Section 4.4.1 about how to start a flash log.
- **Sampling Rate (Hz):** The sampling rate of the high-g accelerometer (maximum 1000 Hz).
- **Range (g):** Sets the maximum acceleration the high-g accelerometer can measure. Select from the supported options in the drop-down list. A lower range has a higher sensitivity.
- **Calibration:** Advanced option that adjusts the scaling and offset of each axis.




**Figure 41: High-G Accelerometer Settings**



### 4.8.7 Temperature Settings

By selecting the *Temperature* configuration option from the sensor tree, the temperature sensor settings can be edited. The settings for the temperature sensor are not related to the CPU temperature from paragraph 4.1.3.4. The settings are shown in Figure 42:

- **Enabled:** Enables sampling of the temperature sensor.
- **Transmit Data:** If the temperature sensor is enabled, data will be transmitted. this is overruled by global transmission settings (see Section 4.8.1).
- **Log to Flash:** If the temperature sensor is enabled, data will be logged to flash. See Section 4.4.1 about how to start a flash log.
- **Sampling Rate (Hz):** The sampling rate of the temperature sensor (maximum 1000 Hz).
- **Range (°C):** Sets the temperature range the temperature sensor can measure, which is -40-85 °C.
- **Calibration:** Advanced option that adjusts the scaling and offset.



**Figure 42: Temperature Settings**



### 4.8.8 GNSS Settings

For ProMove-V sensor nodes that include the GNSS option, the related settings can be configured by selecting the *GNSS* configuration option from the sensor tree. Figure 43 shows the GNSS Settings, with the following parameters:

- **Enabled:** Enables the GNSS sensor and sampling of GNSS data.
- **Transmit Data:** If the GNSS sensor is enabled, data will be transmitted. This is overruled by global transmission settings (see Section 4.8.1).
- **Log to Flash:** If the GNSS sensor is enabled, data will be logged to flash. See Section 4.4.1 about starting a flash log.
- **Sampling Rate (Hz):** The sampling rate of the GNSS sensor (maximum 10 Hz).
- **Static Navigation:** Filters out position jumps when the sensor is stationary.
- **Constellation:** The satellite constellations used by the sensor. This cannot be changed.
- **Other checkboxes:** Include this data in the GNSS sample. The items are described in more detail in Section 4.12.





Figure 43: GNSS Settings



#### 4.8.9 Status Settings

By selecting the *Status* configuration option from the sensor tree, the settings for status samples can be modified. Status samples consist of the battery level, CPU-temperature and external input detection (e.g. whether USB is plugged in). Figure 44 shows the Status Settings, with the following parameters:

- **Enabled:** Enables the status samples.
- **Interval (s):** The interval in seconds at which status samples are transmitted.



**Figure 44: Status Settings**



#### 4.8.10 Sampling Channels

ProMove-V uses sampling channels for each enabled sensor. The *Sampling Channels* information window (Figure 45) shows a summary of the used sampling channels, as follows:

- **Channel:** The channel number assigned to the sensor.
- **Sensor:** The name of the sensor that uses the channel.
- **Wordsize (bit):** The size in bits of one value.
- **Nº Values:** The number of values in a sample.
- **Conversion:** The factor to convert a raw measurement to unit.

The *Status* information is considered to be a separate sampling channel.

Channel	Sensor	Wordsize (bit)	Nº Values	Conversion
0	Accelerometer	16	3	0.0023942
1	Compass	16	3	0.000584454
2	Gyroscope	16	3	0.0610352
3	Accelerometer (High-G)	16	3	0.059855
4	Barometer	24	1	0.000244141
5	Status			
6	Temperature	16	1	0.01

Figure 45: Sampling Channels



## 4.9 Calibrating the Sensors

This section describes how to calibrate the accelerometer, the compass and the gyroscope sensors of the ProMove-V nodes.

We will first explain how to calibrate the accelerometer and the compass. For the accelerometer, all nodes can be stacked and calibrated at once. For the compass, it is recommended to calibrate only one node at a time, to minimize the electro-magnetic influence from other nodes. Create a logfile of at least 30 s as described in Section 4.3. While logging, rotate the node(s) a few times **slowly** around all three axes, at distance from any metal objects. Make sure that on all three axes the minimum and maximum values are reached (for example reach  $-9.8$  and  $9.8 \text{ m/s}^2$  on each accelerometer axes).

For the gyroscope, leave the nodes still on a surface and create a logfile of at least 30 s. In the calibration process, the zero-offset of the gyroscope on all three axes will be determined.

After the calibration logfile was created (with rotations for the accelerometer and compass, or laying still for the gyroscope), open the *Calibration Configuration* shown in Figure 46 via the menu (*Configuration, Sensor Calibration*). Browse to the calibration logfile and click *Calibrate*. By this, calibration results are calculated and the detected nodes are added to the *Node* box.




Figure 46: Calibration Configuration window




Figure 47: Calibration Plot

Select a node and sensor type (accelerometer, compass or gyroscope) to see the calculated *Scale* and *Offset* for each axis. Use *Show Plot* to open a plot that shows the effect of the new scale and offset on the normalized sensor signal (see Figure 47 for the plot of a calibrated compass). The scale and offset can be applied to the node by pressing *Use Results*. The calculated values are loaded into the *Calibration* settings of the node and sensor type in the *Sensor Configuration* window (Section 4.8). Press *Apply Settings* in this dialog to apply the settings.

Note: Calibrating and applying results has to be done for each node and sensor type separately. In general, the calculated scale should be around 1 and the offset around 0. If not, the calibration source file is likely invalid (e.g. no rotation around the y-axis for the compass).



## 4.10 I/O Functionality

The Advanced Inertia Gateway has two BNC I/O ports, each supporting Trigger Output, Trigger Input, Sync Output and Sync Input actions. The I/O ports can be configured for each of these actions in the *Configuration -> I/O Settings* menu, as described in more detail below.

### 4.10.1 Trigger Output

One or both *EXT SYNC* ports can be configured as Trigger Output in the *Configuration -> I/O Settings* menu. Make sure the correct node and port number are selected, then select *Trigger* and *Output* (see Figure 48).




Figure 48: Trigger Output settings




Figure 49: Trigger Input settings


*Trigger (Active)* means that it is already the current selection. Several voltage ranges are possible up to a maximum range of  $-10\text{ V}$  to  $+10\text{ V}$ . Further options exist for inverting polarity and  $50\ \Omega$  impedance driving. The impedance can be set to very high ( $> 1\ \text{G}\Omega$ ) by deselecting the  $50\ \Omega$  impedance.

For the trigger signal itself there are some options as well. Enable the trigger options by checking *Enable Trigger Options*. The trigger type can be either *Pulse* or *Level*. It can be activated in several ways: combined with starting or stopping flash logging, or set manually using the I/O buttons in the toolbar (see Figure 50).

The buttons in the toolbar can be enabled via the menu (*View -> Toolbar -> Show I/O Buttons*)



or directly in the *I/O Configuration* window by checking the checkbox *Show in Toolbar*.



**Figure 50: Inertia Studio toolbar with I/O Buttons**

If the signal is successfully set, a message indicating success appears in the notification area. If the signal is set during logging to file, the event is stored in the log file.

The trigger events are not stored in the flash memory of the nodes. Instead, when starting a flash log, the output signal can automatically be set to *high*. When stopping a flash log, the output signal can be set to *low*. To achieve this, check the checkbox of the gateway in the *Logging to flash* window (see Section 4.4.1) before pressing *Start* and *Stop*.

#### 4.10.2 Trigger Input

One or both *EXT SYNC* ports can be configured as Trigger Input in the *Configuration -> I/O Settings* menu. Make sure the correct node and port number are selected, then select *Trigger* and *Input* (see Figure 49). *Trigger (Active)* means that it is already the current selection. Options are available for inverting polarity and 50  $\Omega$  input impedance. The input impedance can be set to very high ( $> 1 \text{ G}\Omega$ ) by deselecting the 50  $\Omega$  impedance. Enable the trigger options by checking *Enable Trigger Options*. For the trigger input type currently just one option is supported, namely *Edge*.

If *Enable Trigger Options* is active, several actions can be performed when a trigger is received:

**Reset Frame Counter** resets the frame counter as well as the time stamps to 0;

**Send Timestamp Message** sends a time-stamped message to Inertia Studio, which will then appear in the notification area and, if data is being logged by Inertia Studio, in the log file as well.

If the *Hold-off time* is set to 0, the action is performed immediately after the trigger is received. Otherwise, the action is performed after the delay time that is specified here.

#### 4.10.3 Sync Output

One or both *EXT SYNC* ports can be configured as Sync Output in the *Configuration -> I/O Settings* menu. In this mode, a periodic clock signal can be sent to connected devices for synchronization. Make sure the correct node and port number are selected, then select *Sync* and *Output* (see Figure 51).

*Sync (Active)* means that it is already the current selection. Several voltage ranges are possible up to a maximum range of  $-10 \text{ V}$  to  $+10 \text{ V}$ . Further options exist for inverting polarity and 50  $\Omega$  impedance driving.



Finally, the *Sync frequency* and its *Phase shift* can be set to a value between 1 and 1500 Hz for the frequency and at most 1 second for the phase shift.




Figure 51: Sync Output settings




Figure 52: Sync Input settings

#### 4.10.4 Sync Input

Any one *EXT SYNC* port (but not both together) can be configured as Sync Input in the *Configuration -> I/O Settings* menu. In this mode, a periodic clock signal can be received from an external device for synchronization. Make sure the correct node and port number are selected, then select *Sync* and *Input* (see Figure 52). *Sync (Active)* means that it is already the current selection. Options are available for inverting polarity and 50  $\Omega$  input impedance, similar to the other synchronization configurations.

Finally, the *Synchronization frequency* and its *Phase shift* can be set to a value between 1 and 1500 Hz for the frequency and at most 1 second (or less, depending on the frequency) for the phase shift. The given frequency and phase shift are used by the synchronization algorithm in the Gateway to determine what the incoming reference clock signal represents. The timing of the whole system will then be based on this reference.


## 4.11 The Tracker

The *Tracker* window (see Figure 53) can be accessed from the toolbar or via the menu *View*, item *Tracker*. It shows the graphical real-time representation of the orientation of one or more sensor nodes, calculated by the orientation algorithm.

A specific node to track can be selected from the *Node* drop-down list. Tracking multiple nodes at the same time can be done by selecting the *All* option from the drop-down list. The *View* drop-down list allows changing the 3D appearance of the tracked sensor nodes, as follows:

- **Normal:** The nodes are shown as coloured boxes.
- **Model:** The nodes are shown as 3D models of ProMove-V. The colour of the model matches the colour of the node in the legend. A custom model can also be used, see paragraph 4.13.2.5 for more information.
- **Arm:** The nodes are shown as coloured boxes, bound together as arm segments.

The slider can be used to zoom in or out. The *Reset* button resets the orientation algorithm of the nodes (Section 5). The *Order* button shows a dialog where the order of the nodes can be changed, and where nodes can be hidden. Several aspects of the tracker are configurable in the *Preferences* window, see paragraph 4.13.2.5.



**Figure 53: Tracker with six ProMove-V nodes**



## 4.12 GNSS Map

The *GNSS Map* can be accessed from the menu *View*, item *GNSS Map*. It shows the map, the current position and track of the ProMove-V with GNSS sensor, once there is a GNSS position fix. An active internet connection is required in order to display the map.

The GNSS sensor can be configured via the *GNSS Settings* (see Section 4.8.8). In addition to the GNSS column in the legend (see paragraph 4.1.3.2), nodes with no GNSS fix are listed in the bottom-right corner of the map.

The *Settings* checkbox toggles showing the settings in the window. The *Map* and *Plot* radio-buttons can be used to switch between the map-view and the plot-view. The *GNSS Track* checkbox enables showing the GNSS track on the map. The *GNSS Markers* checkbox enables showing a marker for each measurement on the track. The *GNSS Auto-fit* checkbox enables automatic fitting of the GNSS track to the window. Invalid GNSS data can be shown once the GNSS has a valid timestamp fix. Options are *No Fix* for GNSS data with no valid location fix, *Navigation Valid* for GNSS data with a valid location fix and *Velocity Valid* for GNSS data with a valid location and velocity fix.

The *Clear Tracks* button removes the current tracks from the map. The *Fit Tracks* button pans and zooms to map so that all tracks are completely visible. The *Reload* button reloads the entire map window.

The map itself can be controlled using the mouse. Click and drag to change the location of the map. Use the scroll-wheel, shift-click and drag, or the zoom-buttons in the top-left corner to change the zoom-level of the map. Clicking on a part of the track or on a marker shows a popup with the GNSS information at that point.




Figure 54: Map with GNSS track



When switched to plot-view, the map is replaced by plots. The *Plots* button shows a drop-down menu in which the several plots can be shown or hidden. The *Auto-Update plots* checkbox automatically updates the plots to show newly received data. The *Clear* button clears all the data in the plots.

A node needs to have a GNSS fix before data can be shown. The time on the X-axis is the UTC-time received from the GNSS converted to local time. The specific GNSS data needs to be enabled to be able to show it, as described in Section 4.8.8. Also *Date & Time* need to be enabled.

The following GNSS items are available:

- **Latitude** geographic coordinate in degrees that specifies the north–south position.
- **Longitude** geographic coordinate in degrees that specifies the east-west position.
- **Altitude (Ellipsoid)** distance in meters above the reference ellipsoid.
- **Altitude (Mean Sea Level)** distance in meters above the mean sea level.
- **Speed over Ground** the ground-speed in m/s.
- **Course over Ground** the ground-course in degrees.
- **Number of Satellites** the number of satellites used in the GNSS-fix.
- **Horizontal Dilution of Precision** indication for measurement precision.
- **Horizontal Position Error** estimation of the horizontal position error in meters.
- **Vertical Position Error** estimation of the vertical position error in meters.
- **Time Error** estimation of the time error in seconds.
- **Horizontal Velocity Error** estimation of the horizontal velocity error in m/s.
- **Navigation Valid** navigation data is valid (1) or invalid (0).
- **Velocity Valid** velocity data is valid (1) or invalid (0).




Figure 55: Plots with GNSS data



## 4.13 Appearance and Preferences

The appearance of the plots can be changed via the *Preferences* and the *Layout Configuration* windows. The following sections present the configuration options of both windows in detail.

### 4.13.1 Layout Configuration

The *Layout Configuration* window is accessible from the toolbar and via the menu *View*, item *Layout Wizard*. Section 4.13.1 describes how this option can be used to change the type and number of plots that are shown in the main screen.

The layout wizard makes it easy to quickly switch between layouts, or to make a custom screen layout. Simply select one of the predefined layouts from the list and press the *Finish* button. The relevant layouts for ProMove-V are:

- **9D:** Plots of the accelerometer, compass and gyroscope sensors for all three axes.
- **9D+:** Plots of the accelerometer, compass, gyroscope and high-g accelerometer sensors for all three axes, and plots for the pressure, battery, temperature and RSSI measurements.
- **Empty Screen:** No plots are shown.
- **Custom Layout:** The number of plots, the type of sensor data and the location on the main screen can be chosen by the user.


Figure 56 shows the layout wizard set for *Custom Layout*. A custom layout can be created either by modifying the number of visible rows and columns or by changing the plot type using the *Change* button.

In the latter case, the *Plot Selection* window appears, allowing the selection of a different plot type. When the *Only show available sensors* selection box is checked, the window shows only the available sensor types of the connected nodes. Otherwise, the window shows all the available plot types.

Processed data can also be shown in the plots. Available options include the following:

- **Norm:** The normalized value of the axes of a 3D sensor (i.e.  $\sqrt{x^2 + y^2 + z^2}$ ).
- **Orientation:** The orientation of the node, in terms of Euler angles (i.e. *roll*, *pitch* and *yaw*, including FFT values) or quaternions.
- **FFT:** The Fast Fourier Transform, which can be applied to raw sensor signals or processed data (see Section 4.13 for changing the FFT settings).

The *Y-axis label* of each plot can be modified, with the constraint that it must be unique. By pressing the yellow arrow, the label resets to its default value.



**Figure 56: Layout Wizard with custom layout and Plot Selection window**



## 4.13.2 Preferences

The *Preferences* window is accessible from the toolbar and via the menu *Configuration*, item *Preferences*. The four tabs of the *Preferences* window are described in the following sections. After any modification of the preferences, press the *Apply* button to apply them. Press the *Close* button to discard all changes.

### 4.13.2.1 Global

In the *Global* tab, the following preferences can be edited:

- **Small Icons in Legend:** Shows small or large icons in the legend.
- **Automatically Check for Updates:** Checks every week if a new version of Inertia Studio is available.
- **Store Sensor Settings Automatically:** Automatically stores the sensor settings permanently on the node(s), 15 seconds after applying.
- **Automatically Open Export Window:** Open the *Export Logfiles* window (see Section 4.6 when an Export starts).
- **Show Network Adapters:** Shows the network adapters that can be used to connect to an Advanced Inertia Gateway via Ethernet.
- **Down Sampling:** A number of samples can be averaged before showing them in the plot. This improves performance, but shows a flattened signal. Down sampling cannot be applied to FFT plots and has no effect on the values in the log files.
- **Sample Loss Interval (s):** Sets the interval in seconds used for the accumulation of lost samples and calculation of the sample loss percentage, shown in the legend.
- **Plot History (s):** Sets the maximum number of seconds of data to show in the plot (visible when panning the plot).
- **Appearance:** Selects the appearance of the screen - Light, Dark or System.
- **Register File Extensions:** Registers the *itlog* and *fwu* (firmware update file) file extensions to Inertia Studio.




Figure 57: Global Preferences





### 4.13.2.3 Node

In the *Node* tab, the following preferences can be edited:

- **Node number:** Selects a node number for changing its preferences.
- **Description:** A description of the selected node that will be shown in the legend. The yellow arrow will clear the description.
- **Line colour:** Selects the colour to use in the plots for the selected node. The yellow arrow will reset the colour to the nodes default colour.
- **Reset for All Nodes:** Resets the colour and description of all nodes to their default values.





Figure 59: Node Preferences



#### 4.13.2.4 Orientation

In the *Orientation* tab, the following preferences can be edited:

- **Enable Orientation Calculation:** Enables calculating the orientation.
- **Use Compass:** Uses data from the compass for orientation calculation.
- **Reduce Yaw Drift in Rest:** Reduce the yaw-drift when the gyroscope is in rest (all axes at 0). Very small measurements will be ignored.
- **Reset Orientation in Rest:** Resets the orientation when the node stops rotating.
- **Initial Yaw Angle (°):** Sets the initial *yaw* angle (irrelevant when compass is enabled).
- **Algorithm:** Select the algorithm to use to calculate the orientation quaternions.
- **Parameters:** Opens a dialog to modify the parameters of the orientation algorithms.




**Figure 60: Orientation Preferences**



#### 4.13.2.5 Tracker

In the *Tracker* tab, the following preferences can be edited:

- **Show Node Numbers:** Shows the node number next to the 3D model.
- **Show Angles:** Shows the Euler angles (*roll*, *pitch*, *yaw*) in the tracker. In the *Tracker* window, only one node should be selected.
- **Show Wireframe:** Shows the 3D model as a wireframe.
- **Show Axes:** Shows the axes of the ground plane.
- **Use Custom Model:** Chooses a custom 3D model to show instead of the ProMove-V model. The model should be in Wavefront .obj format<sup>1</sup>. After loading, the 3D model is centered and scaled to fit in the tracker.
- **Background Colour:** Changes or resets the background colour of the tracker.
- **Model Size:** Increases or decreases the size of the 3D model.



**Figure 61: Tracker Preferences**


<sup>1</sup>The .obj file should start with three-coordinate vertices followed by three-elements faces. The easiest method to create these files is using MeshLab. First, open or import the model. Then go to the *File* menu and select *Export Mesh (As)...*. Select *Alias Wavefront Object (\*.obj)* as filetype. In the next window, deselect everything (or select *None*) and press *OK*.



#### 4.13.2.6 FFT

In the *FFT* tab, the following preferences can be edited:

- **Window Function:** Selects the window function used by the FFT algorithm. The available options are: *Rectangular*, *Triangular*, *Hamming*, *Hanning* and *Blackman*.
- **X-axis Scale:** Selects the scale of the X-axis as a linear or a logarithmic scale (in decibel).
- **Y-axis Scale:** Selects the scale of the Y-axis as a linear or a logarithmic scale (in decibel).
- **FFT Points ( $2^{\wedge}$ ):** The number of samples used as input for a FFT calculation ( $2^{\text{FFT Points}}$ ).
- **FFT Interval (s):** The time in seconds between subsequent FFT calculations.
- **Remove DC:** Reduce the 0-component by removing the mean DC signal.
- **FFT Averaging:** The number of FFTs to average when plotting.



**Figure 62: FFT Preferences**



## 4.14 Updating the Firmware

The firmware can be updated for all the Inertia devices (e.g. the Inertia Gateway and ProMove-V sensor nodes). The firmware is available for download from the Downloads page of the Inertia Technology website: <https://inertia-technology.com/downloads/>.

The firmware can be updated either using USB or wirelessly.

The *Firmware Update* window can be accessed from the *Help* menu (Figure 63). Available devices are listed on the left, from current and previously opened connections. The icon indicates if a device is connected via USB or wirelessly. When available via both, the USB connection is used. Use the refresh button in the bottom left to clear the connections and devices from the list and refill it with currently opened connections and available devices.

Information about the selected device, including its hardware type, current firmware version, and optional build options is shown in the *Information* box. When a firmware update file (\*.fwu) is selected, its targeted hardware type and firmware version is shown as well.

Use the *Details* button to show more information about the device and firmware file, such as hardware revision and a list of firmware components.




Figure 63: Firmware Update

If no firmware is selected, the device can be reset to its factory defaults by checking *Reset to Factory Defaults* and pressing *Reset*. After resetting, the device has to be manually restarted for the changes to take effect.



The *Progress* box shows information about validating, uploading and reprogramming. When a node is connected and a file selected, *Validating...* shows whether the file is valid and if the supported hardware matches the connected hardware. If valid, the *Reprogram* button becomes enabled. Once the button is pressed, *Uploading...* shows the progress of uploading the firmware to the device. If the upload is successful, the device disconnects and updates the firmware while a *Reprogramming...* countdown timer is shown. When finished, the device reboots and reconnects, and the new firmware information appears in the *Information* box. Only one device per connection can be updated at once, while others will be queued.

**Do not disconnect or turn off the device during reprogramming!**

*Reset to Factory Defaults* clears the current settings and loads the default settings of the new firmware once reprogramming is finished. This reset can also be forced by the firmware update file. In this case, the checkbox cannot be modified. Firmware validation can be disabled to allow programming an unsupported firmware. This could disable the device and should only be done when instructed to do so.

If the firmware update resets the sensor settings, the wireless channel is also reset to the factory settings. After a successful update, if the gateway and the sensor node are on different wireless channels, the sensor node becomes unreachable. For changing the wireless channel of an Inertia device, see Section 4.8.1.

Firmware update does not work if the device does not have internal flash memory, if the internal flash memory is full or (for older firmware) when the maximum number of files is reached.



## 5 The Orientation Algorithm

The orientation algorithm uses inertial sensor data (accelerometer and gyroscope, optionally compass) to calculate the orientation of a node. This is represented in quaternions and Euler angles. The initial *roll* and *pitch* angles relative to the Earth's gravitational field are instantaneously determined using the accelerometer. The *yaw* angle relative the Earth's magnetic field is determined by the compass. If the compass is not enabled, the initial *yaw* provided in paragraph 4.13.2.4 is used. Every new inertial sample is combined with the current orientation to calculate the new orientation. The order for Euler angle rotations is **ZYX**.

For the best performance, the accelerometer and compass should be calibrated as described in Section 4.9. An uncalibrated accelerometer can cause a slight change in the *roll* or *pitch* angles while the node is lying flat. An uncalibrated compass can cause an incorrect *yaw* angle or strange jumps in the *yaw* angle.

There are two situations that have to be considered with respect to the usage of the compass:

- **The compass is used.** Please note that the compass is highly influenced by the surrounding metal objects and electromagnetic fields and therefore it is in general not useful indoors. To be used indoors, the node has to be at least one meter away from any metal object and elevated at least one meter from the ground. In this case, the compass needs to be calibrated (see Section 4.9).
- **The compass is not used.** In this case, the nodes start with the same initial *yaw* angle, which can be configured from *Preferences -> Orientation* (paragraph 4.13.2.4). The computation of the orientation using the compass has to be disabled. There are two options for doing this:
  - Deselect the option *Use compass* from *Preferences -> Orientation* (paragraph 4.13.2.4).
  - Disable the compass sensor from *Sensor Settings* (Section 4.8.3).

At the beginning of an experiment, it is recommended to reset the initial orientation of the algorithm by using the *Reset* button in the *Tracker* window (Section 4.11). In this way, all nodes will start with the correct initial *yaw* angle.



## 6 Performing an Experiment

This section describes how to perform an experiment and how to read and align the data obtained from the experiment.

### 6.1 Experiment Preparation

In order to perform an experiment and to collect data synchronized from multiple nodes, the following steps should be followed:

- Connect the gateway (Section 4.2).
- Check the settings of the gateway (Section 4.8.1).
- Turn on the nodes and verify that data is received from all of them (make sure they are on the same channel as the gateway); verify packet loss and battery level in the legend (paragraph 4.1.3.2).
- Let the nodes warm up and adjust to the ambient temperature in order to reduce the effect of temperature changes on the sensor data.
- Check the settings of the nodes regarding enabled sensors and sampling rates (Section 4.8).
- Calibrate the sensors if necessary (Section 4.9).
- Reset the orientation using the *Reset* button in the *Tracker* (Section 4.11). In this way, all nodes will start with the correct initial *yaw* angle.
- If logging to flash is required (e.g. when filling in lost samples), check the already existing flash logs and perform a format for each node if necessary (Section 4.4.3).
- Open the *Logging Configuration* window and check the settings regarding location of file and other options (Section 4.3)
- If *Export* is enabled, check the export settings (Section 4.6) and file settings, e.g. *CSV Settings* (Section 4.6.1).
- Start recording from *Logging Configuration* window or from the toolbar.
- Stop recording from *Logging Configuration* window or from the toolbar; this step is not necessary if a countdown timer was used (Section 4.3).
- If enabled, confirm and wait for lost samples to be filled in (Section 4.5). In case of missing data (red sections appear in the progress bar), expand the manual settings and press *Start* to restart the process (Section 4.5.2).
- If enabled, wait for file to be exported (Section 4.6).



## 6.2 Reading and Aligning CSV Log Files


Each line in the log file consists of a timestamp and sensor data sampled at that timestamp. A timestamp is the time in decimal seconds since the gateway was started. Figure 64 shows an example log file containing timestamps and sensor data from an experiment.

timestamp	node-id	lostSamples	ax	ay	az	rsi
183.48	23	0	0.244209	-0.174777	10.1993	-52
183.485	23	0	0.258574	-0.181959	10.1921	-52
183.49	23	0	0.237026	-0.179565	10.1873	-52
183.495	23	0	0.253785	-0.169988	10.2017	-52
183.5	23	0	0.241814	-0.189142	10.1825	-52

**Figure 64: Example of a log file**

It is important to align the data from multiple nodes based on the timestamps. In a plot showing sensor data from multiple nodes, the timestamps should always represent the x axis. Figure 65 shows an example of acceleration data from multiple nodes aligned based on timestamps.

Please note that logs from multiple nodes can have different number of samples because the nodes could have started and stopped at slightly different times, they could have different sampling rates, there are lost samples, etc. This is not important, as long as the sensor data is aligned based on the timestamps.



**Figure 65: Example of aligned data from multiple nodes based on timestamps**



## 7 Troubleshooting

### 7.1 Green LED blinks during charging

If the green LED starts blinking during charging, the sensor node does not charge properly. Connect the node to your computer with the USB cable. Press the button to turn the node on and then press it again to turn it off. If the green LED is still blinking, try again the power on and off sequence. If the device does not respond to button press, please see Section 7.2.

### 7.2 Unresponsive Device

If the device does not respond to button press, force the device to turn off by pressing and holding the button for at least 10 seconds.

### 7.3 Retrieving an Unreachable Device

If during network reconfiguration the communication with one device is lost and reconnection is not possible using the procedures described earlier in this manual, please refer to the following steps for device recovery:

1. Connect the device directly to the computer with a USB cable.
2. Click the *Capture* item from the *File* menu and select the serial port associated with the device from the drop-down list. Press the *Start* button.
3. Open the *Configuration* window from the *Options* menu and select *Global* in the sensor tree (see Section 4.8.1). Check the channel number. Change the channel if this doesn't match the configuration of the gateway. *Transmit Data* must be enabled for this node. A mismatch of the sampling rate can also result in sensor data missing in Inertia Studio. Note that unless the transmit type is set to *USB*, the data cannot be captured and shown directly from a wired device.

### 7.4 Slow Signals in Inertia Studio

When using multiple nodes, it is possible that the signals in Inertia Studio are displayed slower, and the software may start to lag. This is likely to be caused by drawing the plots, which is quite CPU-intensive. The following options are available to increase the performance.

#### 7.4.1 Lowering the Plot Update Speed

The *Update Speed* of the signals in Inertia Studio can be lowered and the averaging for the *Down Sampling* can be increased, as described in paragraph 4.13.2.1 and paragraph 4.13.2.2.



### 7.4.2 Reducing the Number of Plots or Nodes

The layout wizard can be used to decrease the number of shown plots (see Section 4.13.1). Decreasing the number of plots lowers the load on the CPU. Reducing the number of nodes that are plotted at once (see Figure 4.1.1) can also improve performance.

### 7.4.3 Enabling Hardware Acceleration and Multi-threaded Rendering

Enabling hardware acceleration (see paragraph 4.13.2.2) will, in general, improve the performance by delegating some of the calculations to the GPU. Using multiple threads to render the plots reduces the load of the main thread and improves responsiveness of the user interface.

## 7.5 Manually Installing the Inertia Driver

If you are unable to install the Inertia Driver via the provided installer, the driver can be installed manually. The following steps describe this procedure for Windows.

1. Connect the Inertia device to the PC. Windows tries to find the correct driver, but fails.
2. Open the *Device Manager* from the *Start Menu* or *Control Panel*. Go to the *Universal Serial Bus controllers* section (ignore the faulty devices in *Other devices* and *Ports (COM & LPT)*).
3. Select and double click *USB Composite Device*. Verify it is the correct one. Go to the *Details* tab and select the *Hardware IDs* property. The value should contain `USB\VID_16D0&PID_090E`.
4. Go to the *Driver* tab and select *Update Driver*.
5. Select '*Browse my computer for drivers*', then select '*Let me pick from a list of available drivers on my computer*'.
6. A list with compatible hardware is shown. If it contains the latest *Inertia Driver*, select it. Otherwise, select *Have Disk...* and browse to the location containing *inertia.inf*. Select *OK* and *Next*.
7. The driver is now installed. The *USB Composite Device* and the faulty devices in *Other devices* and *Ports (COM & LPT)* should disappear, and an *Inertia Device* will appear in the *Ports (COM & LPT)* section.